

IFA511 Komunikasi Antar Perangkat (Internet of Things - IoT)

Communication and Computer Networks

Nur Uddin, PhD.

Program Studi Informatika Universitas Pembangunan Jaya Tangerang Selatan




Computer Network Terminology

- Network: group of computers and associated devices that are connected by communication facilities
- Wide Area Network (WAN): world-wide (Internet)
- Metropolitan Area Network (MAN): city-scale
- Local Area Network (LAN): laboratory/office-scale (Ethernet)
 - WLAN: wireless LAN (Wi-Fi)
 - WPAN: wireless personal area network (Bluetooth)
 - WBAN: wireless body area network



Network Topologies



Topology



Network Protocols

- Protocols are the **building blocks** of a network architecture
- Formal standards and policies enabling communication
- IEEE (Institute of Electrical and Electronics Engineers): standardization
 - Example: Project 802
 - 802.3: Ethernet
 - 802.11: WLAN
 - 802.15: WPAN



Communication

- Who initiates communication?
- Order of communication?
- How long can I talk?
- How loud can I speak?
- Do I have to say something specific at beginning or end?
- Do I have to add meta information?
- What do I do if I get interrupted?
- What do I do if I was not understood?




Hi TCP connection request Hi TCP connection Got the response time? 2:00 Get http://www.awl.com/kurose-ross <file> time

Protocols

N VERSIARS VAR

Client/Server Model

- Client: "active" (initiates communication)
- Server: "passive" (listens and responds)





Client/Server Model Examples

- HTTP (Hypertext Transfer Protocol)
- SMTP (Simple Mail Transfer Protocol)
- SSH (Secure Shell)
- DNS (Domain Name System)
- NFS/AFS (Network/Andrew File System)



Network Protocols ("Protocol Stack")





Figure 2.6



Network Protocols (Headers/Trailers)






Why A Layered Design?

- An explicit structure for dealing with a complex system
- •Simplifies the design process
- Modularity of layers eases maintenance and updating of system components
- Accommodates incremental changes



Open System Interconnection (OSI)





Physical Layer (Layer 1)

• Physical/electrical characteristics

- Cable type, length, connectors, voltage levels, signal durations, ...
- Binary data (bits) as electrical or optical signals
- Frequencies (wireless)


Wireless Characteristics



- VLF = Very Low Frequency
- LF = Low Frequency
- MF = Medium Frequency
- HF = High Frequency
- VHF = Very High Frequency

- UHF = Ultra High Frequency SHF = Super High Frequency
 - EHF = Extra High Frequency
- UV = Ultraviolet Light

- Frequency and wave length
 - $\lambda = c/f$
 - wave length λ , speed of light c \cong 3x10⁸m/s, frequency f






Frequencies for Mobile Communication

• Low Frequencies:

- low data rates
- travel long distances
- follow Earth's surface
- penetrate objects and water (submarine communication)
- High Frequencies:
 - high data rates
 - short distances
 - straight lines
 - cannot penetrate objects ("Line o












Other Propagation Effects


- Shadowing
- Reflection at large obstacles
- Refraction depending on the density of a medium
- Scattering at small obstacles
- Diffraction at edges



Real World Examples








NN VERSIA PS. VAR PAGUNA

Multipath Propagation

• Signal can take **many different paths** between sender and receiver due to reflection, scattering, diffraction




Digital Modulation

• Amplitude Shift Keying (ASK):

- very simple
- low bandwidth requirements
- very susceptible to interference

• Frequency Shift Keying (FSK):

- needs larger bandwidth
- Phase Shift Keying (PSK):
 - more complex
 - robust against interference








Data Link Layer (Layer 2)

• Defines when/how medium will be accessed for transmission


- Units typically called "frames"; error detection/correction; divided into sublayers, including: MAC = Medium Access Control (MAC address 6f:00:2b:23:1f:32)
- Cell phone <u>example</u>:





Example: Ethernet (802.3)


- Most popular LAN technology, uses bus architecture
- Easy to install, inexpensive
- Data is broken into **packets**






Example: Ethernet

- Medium Access Control (MAC) protocol
- CSMA/CD Protocol
 - Carrier Sense
 - Multiple Access
 - Collision Detection






- "Sense" (listen) carrier ("is anyone else talking right now?")
- If "busy": wait; if "idle": transmit
- CD: Keep listening while transmitting
 - If collision detected: retry at a later time



Example: Wi-Fi (802.11)

• Most popular wireless LAN architecture




Access point Wi-Fi router Base station Hotspot



Example: Wi-Fi (802.11)


- CSMA/CA Protocol
 - Carrier Sense
 - Multiple Access
 - Collision Avoidance
 - Channel reservations:
 - Transmitter sends request-to-send (RTS)
 - Receiver sends clear-to-send (CTS)
 - Advantages:
 - Nodes hearing RTS and/or CTS keep quiet
 - If collision, only small RTS or CTS packets are lost





Network Layer (Layer 3)

- Dominant protocol: IP = Internet Protocol
- Addressing and routing (sender & receiver IP address)
- Uses 32 bit **hierarchical address space** with location information embedded in the structure



• IPv4 address is usually expressed in dotted-decimal

notation, e.g.:

128.100.11.56




IPv4

Class A	Netwok	Host	Host	Host
Subnet Mask	255	0	0	0

Class B	Netwok	Network	Host	Host
Subnet Mask	255	255	0	0

Class C Subnet Mask	Netwok	Network	Network	Host
	255	255	255	0

www.smartPCtricks.com






IPv6

- IPv6 addresses are 128 bits long
- 16 bytes of IPv6 address are represented as a group of hexadecimal digits, separated by colons, e.g.:

2000:fdb8:0000:0000:0001:00ab:853c:39a1

• Shorthand – leave out groups of zeros and leading zeros:





Network Protocols ("Protocol Stack")





Figure 2.6

V PENSYARS VAR

Routers

- Form backbone of the Internet
- Use IP layer to identify source and destination of packets
- Look up routing tables that determines "next hop"



Destination	Next Hop
147.39.21.X	131.19.18.121
89.44.X.X	131.19.22.119
203.21.X.X	137.18.47.48



Transport Layer (Layer 4)

• UDP (User Datagram Protocol)

Data

- Adds more addressing: "ports"
 - IP address tell you which computer
 - Ports tell you which application on that computer
 - Example: a web server "listens" to requests on port 80
 - Web browser: <u>http://www.google.com:80</u> = <u>http://216.58.216.100:80</u>
 - ":80": optional
 - Unreliable!
 - Packets can get lost; packets can arrive out of order



Transport Layer

- TCP (Transmission Control Protocol)
- Reliable protocol!
- Adds ports (just like UDP), but also provides:
 - In-order delivery of packets (using sequence numbers)
 - Reliable delivery: using acknowledgment (ACK) packets



• Allows "network" to slow down sender



UDP vs TCP

• TCP:

- typical choice of most applications
- do not want to lose data, out-of-order arrival, etc.
- email, web traffic, financial transactions, etc.
- UDP:
 - can be "faster"
 - no flow/congestion control "slowing down" traffic
 - no retransmissions
 - good for "real-time" traffic
 - out-of-order arrival: can also "reorder" at application level
 - loss of data: can be acceptable
 - missing frames in video/audio stream




Upper Layers (Layers 5-7)

- Session Layer
 - Management of "sessions"
- Presentation Layer
 - Data translation, formatting, encryption, compression
- Application Layer
 - Interface between user applications and lower network services




Example: Web Servers





Example: Web Servers





Example: Web Servers

